

6 BURNER STOVE WITH OVEN

Item # 1457

845.226.2447

BURNER INSTRUCTIONS

- TURN ON GAS SUPPLY AND IGNITE THE PILOT FLAME WITH A LIGHTER. IGNITION MAY TAKE ABOUT 2 – 3 MINUTES.
- PRESS THE CORRESPONDING VALVE KNOB OF BURNER AND TURN 90 DEGREES COUNTER-CLOCKWISE. THE BURNER WILL BE IGNITED, AND THE FLAME WILL BE AT MAXIMUM.
- WHEN FINISHED TURN OFF MAIN BURNER BY ROTATING KNOB CLOCKWISE TO THE OFF POSITION. PILOT SHOULD REMAIN LIT.
- FOR COMPLETE SHUTDOWN, ENSURE THAT ALL BURNER KNOBS ARE TURNED TO THE OFF POSITION, AND THEN TURN OFF MAIN GAS SUPPLY.



POWER REQUIREMENTS:

Propane

SPACE REQUIREMENTS:

Must be a distance of 6" from other equipment.

OTHER REQUIREMENTS:

100 lb propane tank

OVEN INSTRUCTIONS

- TO IGNITE, OPEN THE KICK PANEL (LIFT UP AND PULL OUT) THEN PRESS DOWN THE OVEN KNOB AND ROTATE IT COUNTERCLOCKWISE TO THE . ALIGN AND PRESS DOWN. IGNITE THE PILOT FLAME WITH LIGHTER VIA THE IGNITION HOLE.
- AFTER THE PILOT FLAME IS IGNITED, CONTINUE PRESSING THE KNOB FOR AROUND 30 SECONDS. IF THE PILOT LIGHT GOES OUT AGAIN WHEN YOU RELEASE THE KNOB, REPEAT THIS OPERATION.
- ONCE PILOT REMAINS LIT, ROTATE THE TEMPERATURE CONTROL KNOB COUNTER-CLOCKWISE TO IGNITE THE MAIN BURNER OF THE OVEN. SELECT YOUR TEMPERATURE.
- TO TURN OFF BURNER, ROTATE THE KNOB CLOCKWISE TO STRIP MARK AND ALIGN WITH .



BURNER PILOT LIGHTS



OVEN PILOT LIGHT